

# ТАБЛИЦА СОВМЕСТИМОСТИ

от 15.04.2011

Модели струйных принтеров Epson	3 (5) в 1	I grey	cyan	I cyan	magenta	I magenta	yellow	black	Matt black	grey	red	green	blue	glossy	orange	тип чернил	количество цветов
Epson C42\C44	T037040							T036140									4
Epson C43\C45	T03904A							T03814A								водные (Dye) серия 1	4
Epson C48	T067040							T066140									4
Epson C62\CX3200	T041040							T040140									4
Epson C63\C65\CX3500			T04724A		T04734A		T04744A	T04614A									4
Epson C64\C84\C86\CX6400\CX6600			T044240		T044340		T044440	T043140									4
Epson C70 \ C80			T032240		T032340		T032440	T032140									4
Epson C82\CX5200\CX5400			T042240		T042340		T042440	T032140									4
Epson C67\C87\C87Plus\CX3700\CX4100\CX4700			T06324		T06334		T06344	T06314								пигмент DURABrite Ultra серия 32	4
Epson Photo R200\R220\R300\R300ME\R320\R340 RX500\RX600\RX620\RX640			T048240	T048540	T048340	T048640	T048440	T048140								водные (Dye) серия 2	6
Epson Photo RX700			T559240	T559540	T559340	T559640	T559440	T559140									6
Epson Photo R240\RX520			T055240		T055340		T055440	T055140								водные (Dye) серия 11	4
Epson Photo 740\760\860\1160	S020191 (T052040)							S020209 S020189 (T051142)									4
Epson Photo 790\870\890\895\915	T008401							T007401, T007402								водные (Dye) серия 1	6
Epson Photo 810\830\830U\925\935	T027401							T026401									6
Epson Photo 820	S02049							S02047									6
Epson Photo 900\1270\1290\1290S	T009401							T007401, T007402									6
Epson Photo 950			T033240	T033540	T033340	T033640	T033440	T033140 (2)									7
Epson Photo 2100\2200			T034240	T034540	T034340	T034640	T034440	T034140, T034840		T034740						пигмент (UltraChrome) серия 21	7
Epson Photo R2400		T059940	T059240	T059540	T059340	T059640	T059440	T059140		T059740						пигмент (UltraChrome K3) 21 и I.grey 24 серия	8
Epson R1900			T054240		T054340		T054440	T054140	T054840		T054740		T054940	T054040		пигмент, 19 серия	8
Epson Photo R800\R1800			1		1		1	1								пигмент серия 8 (UltraCrome Hi-Gloss)	6
Epson PictureMate\PictureMate 500																	8
Epson Stylus C79\CX3900\CX4900\CX5500\CX5900\CX6900F\CX7300\CX8300\CX9300F T40w\TX300F\TX600fw TX200\TX209\TX400\TX409\X209\TX210\TX219\TX410\TX419\TX550W (версия чипов 5.1)			T07324N		T07334N		T07344N	T07314N								пигмент DURABrite Ultra 13	4
Epson Photo R270\R390\RX590\1410\RX610\RX690\R290\R295\RX615 T50\T59\TX700W\TX800FW\TX710W\TX650\TX659 (версия чипов 5.1)			T08224	T08254	T08234	T08264	T08244	T08214								водные 12 серия	6
Epson Photo P50 (версия чипов 5.1)			T08224	T08254	T08234	T08264	T08244	T08214									6
Epson T1100			T01032		T01033		T01034	T0721(2)									4
Epson Stylus C110\C1100			T07324		T07334		T07344	T07314(2)								пигмент DURABrite Ultra 13 серия	4
Epson Stylus Office T30\TX510(версия чипов 5.1)			T09224		T09234		T09244	T09214									4
Epson Stylus C91\CX4300			T1282		T1283		T1284	T1281									4
Epson Stylus Photo S22\SX125\SX420W\SX425W\SX525WD\BX305F\BX320FW\BX625FWD (НОВАЯ ЛИНЕЙКА)			T0802	T0805	T0803	T0806	T0804	T0801 T0791								водные 12 серия	6
Epson Stylus PX700W\PX800FW Series			T0792	T0795	T0793	T0796	T0794										6
Epson Stylus Photo 1900			T08724		T08734		T08744	T08714	T08784		T08774			T08704	T08794	пигмент (UltraCrome Hi-Gloss) серия 19	8
Плоттеры Epson Stylus Pro 4000\7600\9600			T543200	T543500	T543300	T543600	T543400	T543100		T543700 or matte T543800						пигмент UltraChrome 21 серия	7

Модели струйных принтеров Canon	3 в 1	cyan	photo cyan	magenta	photo magenta	yellow	black	серия чернил	количество цветов
Canon ip1000\ip1500\ip2000\mp110\mp130\i470d\i475d\i250\i320\i350\i455\i200x\i300\i330	BCI-24C						BCI-24Bk	4 серия	4
Canon ip1200\ip1300\ip1600\ip1700\ip1800\ip1900\ip2200\ip2500\ip2600 mp150\mp170\mp210\mp220\mp450\mp160\mp180\mp460\mx300\mx310	CL41						PG40	10 серия	4
Canon ip3000\i560		BCI-6C		BCI-6M		BCI-6Y	BCI-3eBk BCI-6Bk	5 серия	4
Canon ip4000\ip5000\i865\mp750\mp760\mp780		BCI-6C		BCI-6M		BCI-6Y	BCI-3eBk, BCI-6Bk	5 серия	5
Canon ip4200\IP4300\ip4500\IP5200\IP5300\ip5300R mp500\mp530\mp610\mp800\mp810\mp800R\mp830 mx850		CLI-8C		CLI-8M		CLI-8Y	CLI-8Bk, PGI-5Bk	10 серия	5
Canon ip3600\ip4600\mp540\mp620\mp980\ip4700		CLI-8C		CLI-8M		CLI-8Y	CLI-8Bk, PGI-5Bk	10 серия	5
Canon ip6000d\i905d\i950\i965\i800\i820d\i830d\i8200\i9100\i900\i9000		BCI-6C	BCI-6PC	BCI-6M	BCI-6PM	BCI-6Y	BCI-6Bk	5 серия	6
Canon ip6600D\6700D ip6210D\ip6220d		CLI-8C	CLI-8PC	CLI-8M	CLI-8PM	CLI-8Y	CLI-8Bk	10 серия	6
Canon i6500\mp700\mp730\i550\i850\i500\i520\i530d\i630\i750\i6300		BCI-3eC		BCI-3eM		BCI-3eY	BCI-3eBk	6 серия	4
Canon i9950\i8500		BCI-6C	BCI-6PC	BCI-6M	BCI-6PM	BCI-6Y	BCI-6Bk	5 серия	8
Canon ix4000\ix5000\ip3300\ ip3500\MP510\mp520\mp780		CLI-8C		CLI-8M		CLI-8Y	PGI 5Bk	10 серия	4

Номера оригинальных картриджей HP и модели принтеров	номера чернил RDM	цвета
29 (51629a), 45 (51645a\g), 15 (c6615a\d), 40 (51640a)	29/45	black
26 (51626F)	26	black
78 (c6578a), 41 (51641a), 23 (c1823d), 25 (c51625a)	25/78	cyan magenta yellow
27 (c8727a), 56 (c6656a)	27/56	black
28 (c8728a), 57 (c6657a)	28/57	cyan magenta yellow
58 (c6658a)	58	black cyan magenta l.magenta l.cyan
131 / 132	131 / 132	black
177 и cyan 71/75 (принтеры 8230/8238/8250/8253/5183/7283/7163/7363/7463)	30 (8721/8772/ 8773/8775)	black magenta l.magenta l.cyan yellow и cyan
178	31	black, photo black
135 / 136	135/136	cyan magenta yellow black

Модели плоттеров HP	номера чернил RDM
HP Designjet 100 \110 plus (4 цв. - B\C\M\Y)	HP №27\56 (B) и HP №28\57 (C\M\Y)
HP Designjet 120 (82 картридж) (6 цв. - B\C\Lc\M\Lm\Y)	HP №57 (C\M\Y) и HP №58 (B\Lc\LM)
HP Designjet 130 (11 картридж) (6 цв. - B\C\Lc\M\Lm\Y)	HP №57 (C\M\Y) и HP №58 (B\Lc\LM)
HP Designjet 500\800 (4 цв. - B\C\M\Y)	HP №27\56 (B) и HP №28\57 (C\M\Y)
HP Designjet 3000 (95 картридж) (4 цв. - B\C\M\Y)	HP №27\56 (B) и HP №28\57 (C\M\Y)
HP Designjet 5000\5500 (81 или 83 картридж) (6 цв. - B\C\Lc\M\Lm\Y)	HP №57 (C\M\Y) и HP №58 (B\Lc\LM)
HP (177 картридж) 8230\8238\8250\8253\5183\7283\7163\7363\7463	HP №30

www.rdmkit.ru  
тел. +7(343)222-15-11

г.Екатеринбург, пр-кт Ленина 54/2

